


Straight Cutter – Fitting the Blade

The guard should be kept on the cutter when not in use

For Right Handed use:


1. Pick up the cutter in one hand.
2. Hold the end of the blade with your other hand between finger and thumb.



3. Slide the blade into the raised slot on the cutter.

For Left Handed use:

1. Pick up the cutter in one hand.
2. Hold the end of the blade with your other hand between finger and thumb.



3. Slide the blade into the raised slot on the cutter.

4. Secure the blade with the blade screw.



**Vertical Cutter showing blade fitted for
Left Hand and Right Hand Use respectively**

When not in use always keep the Straight Cutter in its Foam Safety Guard

